

**Akku - Bez.****passend zu Kamera Modell**

<b>BP-511A</b>	<b>EOS 5D, 10D, 20D, 30D, 40D, 50D, D60, 300D, Kiss Digital PowerShot G5 90</b>
<b>BP-808 BP-809 BP-827</b>	<b>HF G10, S10, S21, S30, S100, S200, FS11, HF11, HF20,LEGRIA</b>
<b>BP-945 BP-911</b>	<b>ES50, ES55, ES60, ES65, ES75, ES7000V, G10 DM-XL1</b>
<b>LP-E10 LPE10</b>	<b>EOS 1100D, 1200D, 1300D, Rebel T3, T5, T6, Kiss X50, X70</b>
<b>LP-E12 LPE12</b>	<b>EOS 100D, M, M10, M2, M50 Mk II, M100, Rebel SL1</b>
<b>LP-E17</b>	<b>EOS 77D, 750D, 760D, 8000D, Rebel, T6i, T6s, Kiss X8i</b>
<b>LP-E5 LPE5</b>	<b>EOS 450D, 500D, 1000D, Kiss F X2, X3, Rebel XS, Xsi</b>
<b>LP-E6 LP-E6N</b>	<b>EOS 5D, 6D, 7D, 60D, 60DA, MARK II, MARK III</b>
<b>LP-E8 LPE8</b>	<b>EOS 550D, 600D, 650D, 700D, Kiss X4, X5, X6, Rebel T2i, T3i, T4i, T5i</b>
<b>NB-10L</b>	<b>PowerShot G1 X, G3 X, SX40, HS SX50, HS SX60, HS G15, G16</b>
<b>NB-11L</b>	<b>IXUS 125HS, 240HS, 265HS, 275HS, 285HS, PowerShot ELPH 110HS, 320HS, 340HS 9</b>
<b>NB-12L</b>	<b>Powershot G1 X Mark II, N100 LEGRIA mini X</b>
<b>NB-13L</b>	<b>PowerShot G1, G5, G7,G9 X Mark II, SX620 HS SX720</b>
<b>NB-2L</b>	<b>PowerShot G7, G9, S70, S80, R100, R11, Canon Elura 85, 90</b>
<b>NB-2L / NB-2LH</b>	<b>PowerShot G7, G9, S70, S80, R100, R11, Canon Elura 85, 90, EOS 350D, 400D</b>
<b>NB-3L</b>	<b>Digital IXUS II/lis i5 L3 30 D30 600 750 PowerShot SD10, SD100, SD550</b>
<b>NB-5L</b>	<b>PowerShot SX220HS, SX230HS, Digital IXUS 90IS, 800IS, 850IS, 860IS</b>
<b>NB-6L</b>	<b>PowerShot ELPH 500HS, SX 240HS, 260HS, 270HS, 280HS, 510HS, 520HS, 530HS</b>
<b>NB-7L NB7L</b>	<b>PowerShot SX30, IS G10, G11, G12</b>
<b>NP-E3</b>	<b>EOS-1D Mark II, EOS-1Ds Mark II, EOS-1Ds EOS-1D Mark II N</b>